



CVL(1) color desk-viewing light(Color light box)

Product Information

Brand: INTEKE

CVL(1) color desk-viewing light(Color light box)

CVL(1) color desk-viewing light is specially designed for observing transitive and reflective originals when they are being processed in the prepress stage. The aim is to provide a standard color viewing environment for color management in this area. Hence, the color of the processed image shown on the computer screen will match the color of the original image observed under the same light source.

CVL(1) color desk-viewing light Specifications

Dimension(mm): 660W*500D*330H

Illuminance area(mm): 580W*330D Tube parameter:

Power: 13W Color temperature: D50

Length: 517mm Quantity: 2